

900 Series Precision Process Controller

QUICK SETUP INSTALLATION

- 1 Connect input or output into the desired instrument port as shown.
- 2 Insert power plug into PWR jack as shown.
- 3 Plug the D9 part of a (C75100AA) RS-232 cable into a computer serial port. Insert the plug on the other end of the cable into the 990 SIO IN jack as shown.
- 4 When your unit is installed with the WAN modem option then plug either end of a (C75106AG) cable (RJ-11) into the corresponding jack and the other end of the cable into a standard telephone jack as shown.
- 5 When relay output option is installed then plug the (C17221AA) cable into the REM jack and connect the wires shown to the controlled equipment.
- 6 When analog output option is installed then plug the (C75103ZZ) cable into the REM jack and connect the wires shown to the controlled equipment.

